


MANUAL – IOB SUITE 2.02

www.plcdesign.xyz



INDEX

00-Introduction to IOB Suite 2

01-Content and installation of the downloaded .ZIP file

01.01-Installation process of “IOB Suite” after downloading (Trial version) 5

01.02-Installation process of “IOB Suite” after downloading (PRO/STD version) 6

02-Excel® features that do not work with “IO_Builder.exe” 7

03-Issues during the installation process of IO_Builder.exe 7

04-How to update “IOB Suite” 9

05-How to move/copy IOB_Suite to another project folder..... 9

06-How to save IO_Builder.exe and run a .xlsc file 9

07-Digital Signature of “IO_Builder” 10

08-About execution speed of Excel 11

09-Work flow to generate I/O List (in project execution phase)..... 12

10-Import tags and other data from another Excel file (IOB Utilities)

10.1-Preparation of external I/O List before importing it 13

10.2-Import external I/O List..... 17

10.3-Special case: Import single signals by groups..... 19

11-Label Generator (IOB Utilities)..... 20

12-Add Prefixes / Suffixes (IOB Utilities)..... 21

13-Export I/O List to another Excel file (IOB Utilities)..... 22

14-Modified Rows per page of exported I/O list (IOB Utilities)..... 23

15-Manage data list within IOB Utilities (sheets IO_DB & Enterfields)..... 24

16-How to make an architecture drawing (IOB_Utilities)..... 24

17-Introduction to IO Builder.exe 25

18-Make a distribution of redundant & non redundant I/Os (IO Builder.exe)..... 27

19-Price Comparison 36

20-How to add I/Os to an existing architecture 37

21-License Agreement 47